

Expander Single Instruction for use

Congratulations!

With your purchase you have decided on a high-quality product. Get to know the product before you start to use it. Carefully read the following instructions for use. Use the product only as described and only for the given areas of application. Keep these instructions safe. When passing the product on to a third party, always make sure that the documentation is included.

Failure to observe the safety notes can lead to serious injuries.

Scope of delivery

1 x Expander 1 x Instructions for use

Technical data (Metric)

Expander length (including handles): approx. 100cm Handles: diameter: 3cm, length: 15cm

Technical data (Anglo-American)

Expander length (including handles): approx. 40" Handles: diameter: 1,2", length: 6"

Wood: American Walnut or Canadian maple, brass Rubber band: highly elastic core and PE coating

Correct use

This article was developed as a training instrument with which you can train your entire body. The expander is designed for private use and is not suitable for medical and commercial purposes.

! Warning! Risk of injury !

Consult your doctor before beginning training. Please ensure (1/2)

(2/2)

that your health is suitable for training. Remember to warm up always before training and train in accordance with your current performance capability. Serious injury can occur if training is excessive or too strenuous. Stop training immediately and contact your doctor if you experience discomfort, weakness, or fatigue.

The article may only be used under adult supervision and not as a toy. Keep the instructions for use with the exercise descriptions to hand at all times. Safe training requires sufficient space. Carry out the exercises with enough distance from objects and other persons that nobody can be injured. Only train on a flat, non-slip surface. Do not use the article close to stairs or steps. Never pull the article in the direction of your face and never wrap it around your head, neck, or chest. A free area of approx. 0.6 m / 2' must be kept around the training area.

! Particular caution - Risk of injury for children!

Do not allow children to use the equipment without supervision. Instruct them regarding the correct use of the training instrument and supervise them. Only allow use if the mental and physical development of the children allows it. This article is not suitable for use as a toy.

! Hazards from wear !

General training notes

movements

out the exercises.

Warming up

Neck muscles

again

movement 4-5 times.

Arms and shoulders

one minute backwards.

muscles are warmed up optimally.

change direction after one minute.

Wear comfortable sports clothing and shoes.

Slowly increase the training intensity.

The article may only be used in perfect condition. Inspect the article for damage and wear before each use. The safety of the article can only be guaranteed if it is inspected regularly for damage and wear. Discontinue use if damage is found.

Pay particular attention to the expander bond during your examination. Discontinue use of the article if you find tears in the parts or the expander bond. Only use original replacement parts. Protect the article from extreme temperatures, sun, and moisture. Incorrect storage and use of the article can lead to premature wear, which can lead to injuries.

Warm up before each training session and end the training gradually.

Take sufficiently long breaks between the exercises and drink enough fluids. As a beginner you must never train with too much resistance.

Carry out all the exercises steadily without too much speed or jerky

Make sure you breathe at a steady rate. Breathe out with effort and in

upon recovery. Make sure you keep a correct posture while carrying

Take enough time to warm up before each training session. The following section is a description of some simple exercises for this

1. Turn your head slowly to the left and to the right. Repeat this

2. Circle your head slowly, first in one direction and then in the other.

1. Close your hands behind your back and pull them carefully up-

2. Circle both your shoulders forwards at the same time and then

3. Pull your shoulders up to your ears and let your shoulders fall

4. Circle your right and left arms alternately forwards and then after

Important: Don't forget to continue breathing steadily throughout!

wards. If you bend your upper body forwards at the same time all the


purpose. You should repeat each exercise 2 or 3 times.

.....

This product is made for one-handed exercises and needs to be mounted to a doorknob or wall-hook etc.







Shoulder and biceps

Starting position

 Stand with your feet hip-width apart and your legs slightly bent. Take hold of the handle with one of your arms on extension of your shoulder axis. The rubber band is slightly tensed.
Spread your weight evenly across both feet. Your upper body is

upright. Tense your stomach and chest muscles.

End Position

Tense your arm muscles and pull your arm to your chest. Your head is an extension of your spine and your shoulders stay down.
Hold this position for a moment and then return slowly to the starting position.

6. Repeat this exercise 10 -15 times for three sets, then change sides

Important: Please ensure that your upper body is straight.

Triceps

Starting position


 Stand with your feet hip-width apart and your legs slightly bent.
Spread your weight evenly across both feet and bend your knees slightly. Your upper body is upright.

3. Take hold of the handle with your right hand from behind in such a way that the band runs along the right side of your back. Your right hand is above your right shoulder.

End position

 Tense your arm and stomach muscles and pull your right arm upwards behind your head. Your upper arm is close to your head. Pull your shoulder blades towards your spine. Your head is an extension of your spine and your shoulders stay down.
Hold this position for a moment and then return slowly to the starting position.

6. Repeat this exercise 10 -15 times for three sets and then change sides.



Lateral stomach muscles and chest

Starting position

1. Stand with your feet hip-width apart and your legs slightly bent with your back towards the mount

 Spread your weight evenly across both feet and bend your knees slightly. Your upper body is upright.
Take hold of the handle with your right hand in such a way that

your arm is on extension to the rubber band.


End position

4. Tense your arm and stomach muscles and pull your right arm towards your chest. Your upper arm is close to your upper body. Pull your shoulder blades towards your spine. Your head is an extension of your spine and your shoulders stay down.

5. Hold this position for a moment and then return slowly to the starting position.

6. Repeat this exercise 10 -15 times for three sets and then change sides.





¢

Triceps

Starting position

1. Stand with your feet hip-width apart and your legs slightly bent with your front towards the mount.

2. Spread your weight evenly across both feet and bend your knees slightly. Your upper body is upright.

3. Take hold of the handle with your right hand in such a way that your arm is on extension to the rubber band.

End position

4. Tense your arm and shoulder muscles and pull your slightly bent arm parallel to your body to your hip. Your upper arm is close to your body. Pull your shoulder blades towards your spine. Your head is an extension of your spine and your shoulders stay down.

5. Hold this position for a moment and then return slowly to the starting position.

6. Repeat this exercise 10 -15 times for three sets and then change sides.

ס

Stretching

Take sufficient time to stretch after each training session. Some simple exercises are described below. Carry out each exercise 3 times each per side for 15-30 seconds.

Neck muscles

1. Stand in a relaxed pose. Use your hand to pull your head gently to the left and then to the right. This exercise stretches the sides of your neck.

Arms and shoulders

1. Stand upright with your knees slightly bent.

2. Lay your right arm behind your head until your right hand is between your shoulder blades.

3. Hold your right elbow with your left hand and pull it backwards.

4. Change sides and repeat the exercise.

Care, storage

Always store the article in dry and clean condition at room temperature. Never clean it with aggressive cleaning materials but rather wipe it clean with a dry cleaning cloth. Protect the article from extreme temperatures, sun, and moisture. Incorrect storage and use of the article can lead to early wear, which can cause injury.

Disposal

Dispose of the article and the packaging materials in accordance with current local regulations. Packaging materials such as foil bags are not suitable to be given to children. Keep the packaging materials out of the reach of children.

One-handed rowing

Starting position

1. Stand with your feet hip-width apart and your legs slightly bent with your front towards the mount.

2. Spread your weight evenly across both feet and bend your knees slightly. Your upper body is upright.

3. Take hold of the handle with your right hand in such a way that your arm is on extension to the rubber band.

End position

 Tense your arm and shoulder muscles and pull your right arm back until your right hand is next to your chest. Your upper arm is close to your upper body. Pull your shoulder blades towards your spine. Your head is an extension of your spine and your shoulders stay down.
Hold this position for a moment and then return slowly to the starting position.

6. Repeat this exercise 10 -15 times for three sets and then change sides.



Have fun! Visit us on kenkostores.com & instagram.com/kenkostores

For any inquiries: Kenko GmbH Niemetzstraße 41, Tor 9 12055 Berlin

info@kenkostores.com